

Auto-Print™ Bagging System

Overwrapping Solution for Ancillary Packaging



Vials



Ampoules



Syringes



Auto-Print™ Bagging System

(Manufactured by Sharp Packaging Systems, Inc.)

The **Auto-Print Bagging System** provides the capability of loading, printing, bar coding and sealing your ancillary parenteral medications in just a few simple steps. These features virtually eliminate mislabeled bagged products and the expense of scrapping “in between print” bags.

The Auto-Print™ Bagging System is an all-electric, tabletop bagging system. Bags are blown open through an internal fan, which channels high volume, low pressure, ducted air into the bag for easy product loading.

Utilizing Medical Packaging Inc.'s powerful Pak-EDGE™ Barcode Labeling Software, the Auto-Print™ Bagging System produces bar codes based on many of the popular symbologies being used in the healthcare industry.

Labeling and bar coding is done directly on the bag, eliminating costly labels and allowing the facility to customize their bar code and packaging procedures.

- Seals the bag completely each time, delivering consistent, tamper-evident seals.
- Uses off-the-shelf parts. Fewer parts mean minimal maintenance and less down time.
- Simple, fast bag roll changes improve productivity.
- 4-color backlit control panel for easy readability.
- Self-Diagnostic trouble shooting allows for quick resolution of problems.
- Bag size is stored with the label format for instant bag size changeover.

- No print registration marks required.
- Automatic paced-rate operation is provided with adjustable fill time delay.
- A variety of different sized bags are available in stock and custom sized bags can be ordered to meet the unique needs of all customers.

Technical Specifications	
Dimensions:	26.25" L x 33.50" W x 19.00" H
Weight:	200 lbs.
Power:	110VAC, 60Hz, 5 Amps 220VAC, 50Hz, 5 Amps
Operating Temp:	0-40°C, 32-140°F
Humidity Range:	10% - 90% RH Non-Condensing
Rate:	35 Doses/Minute

All MPI packaging systems require the use of MPI authorized disposable materials.



Medical Packaging Inc. • 470 Route 31 • P.O. Box 500 • Ringoes, NJ 08551
Toll free. 800.257.5282 | Fax. 609.466.3775 | www.medpak.com

Auto-Print and Pak-EDGE are trademarks of Medical Packaging Inc. Windows is a registered trademark of Microsoft.